

-- IMPORTANT --
SAFETY DATA ON TANNER® DE-ICING UNITS

TANNER® DE-ICERS, MODELS: T-83, T-85, T-87, T-89 or T-90

MAXIMUM WORKING PRESSURE is 200 p.s.i.g.
Maximum Internal Air Temperature is 150° F.
DO NOT EXCEED these limits!

LOCATION – DO NOT locate near fire, intense lamps or other excessive heat.
Install unit as close as possible to freezing problem.

INSTALLATION – DO NOT support units by hoses or pipe alone.

FILLING –

- **READ product LABELS and SDS prior to filling.**
- **Use only TANNERGAS®/FREEZE-BAN or NO-TOX2® fluids in these units.**
- **DO NOT SMOKE while filling or handling!!**
- **If filling under pressure, first bleed air SLOWLY from tank through Fill Plug R-20 or Bleed Plug R-36.**
- **AVOID SPILLS! If spilling should occur handle in accordance with your company policy and local, state and federal regulations.**

ADJUSTING –

DO NOT REMOVE Adjusting Screw R-34 completely when unit is under pressure – refer to Parts/Instruction sheet included with each De-Icer.

TANNER® TANKS, MODELS: T-30A, T-40A or T-60

MAXIMUM WORKING PRESSURE is 200 p.s.i.g.
(Higher pressure available by special order)

LOCATION – DO NOT locate near fire, intense lamps or other excessive heat.

INSTALLATION –

Refer to Form TT-IN and TTP for placement and complete instructions.

FILLING –

- **READ product LABELS and SDS prior to filling.**
- **Use only TANNERGAS® fluid in these units.**
- **DO NOT SMOKE while filling or handling!!**
- **When filling UNDER PRESSURE, be sure that proper VALVES ARE CLOSED.**
- **BLEED AIR SLOWLY from tank when opening Gate Filling Valve W-16.**
- **AVOID SPILLS! If spilling should occur, handle in accordance with your company policy and local, state and federal regulations.**

-- IMPORTANT --

SAFETY DATA ON TANNER® DE-ICING UNITS

TRI-FLUID INJECTORS, MODELS: TFIA or TFIB

MAXIMUM WORKING PRESSURE is 150 p.s.i.g. (500 p.s.i.g. with modifications)
(In 2014, TFIA & TFIB replaced TFL86 & TFI3.4)

LOCATION – DO NOT locate near fire, intense lamps or other excessive heat.

INSTALLATION – Refer to Form TFIA-B INS for placement and complete instructions.

FILLING –

- **READ** product LABELS and SDS prior to filling.
- Use TANNERGAS®, NO-TOX2® or FROSTO® fluid in these units.
- **DO NOT SMOKE** while filling or handling!
- **TURN OFF** all ELECTRICAL SERVICE to unit prior to filling.
- **TURN OFF** ¼" pad airline at tank using the ball valve next to pressure regulator (H-26).
- **BLEED AIR PRESSURE SLOWLY** from Supply Tank H-23 by **SLOWLY** opening the 1 ½" pipe cap on the 45° elbow on the side of the tank. Do not **OVERFILL**.
- **AVOID SPILLS!** If spilling should occur handle in accordance with your company policy and local, state and federal regulations.

NOTE: ALL PARTS AND INSTRUCTIONS SHEETS REFERRED TO ON THIS FORM ARE AVAILABLE ON OUR WEBSITE.

TANNER SYSTEMS, INC.

P.O. Box 488 * St. Joseph, MN 56374

Phone: (320) 363-1800

Toll Free: (800) 461-6454

FAX: (320) 363-1812

Website: www.tannersystems.com * Email: info@tannersystems.com